


V1.0 305503000795

#### Setting Up Your Foscam Security Camera


#### **1** Getting Started

#### Package Contents



#### Security Tips

- Please change the camera's password regularly, using a combination of numbers, letters and special characters.
- We recommend that you regularly update your camera with the latest available software and firmware to ensure the best experience with your camera



specifications:

- iOS: version 8.1 or higher.
- Processing

version!

#### Wired Connection

vertical position.

#### **3** Setting Up Your Camera: Wired Connection via the Foscam App (Recommended)


#### **Before You Get Started**

Scan the QR code below to download and install the Foscam APP.




- To ensure a smoother video experience on your smart phone, it is recommended that your smart phone meet the following
- Android: 4.1 or higher, using a device with a Graphics
- **Note:** For the best experience, please update the APP to the latest

1. Please tighten the antenna clockwise and make sure it is in a



2. Connect the camera to your router with an Ethernet cable.

- 3. Plug the power adapter into the camera, and then wait for about 1 minute.
- 4. Make sure your smart phone is connected to the same WiFi network as the camera.






Tips: The camera supports dual-band 2.4GHz and 5GHz WiFi networks, so you can choose the channel with the stronger signal to use. For example, choose your SSID: XXXXX\_2.4G or XXXXX\_5G.

5. Open the foscam APP and please register a Foscam account, or sign in if you have one already.




6. Follow the steps below:






) Search in

Manually add







**Note:** If the adding process fails, please reset your camera and try adding again according to the above method.

< Camera Login

New camera usernar

New camera passwor

Re-enter new camera


Submit

password



#### Configure WiFi

If you selected "**Skip**" in (9), click play to enter the camera credentials interface > Tap the " $\bigcirc$ " button > tap "WiFi Settings" > select your WiFi network and enter your WiFi's password. After setting up successfully, you can view live video without the Ethernet cable



#### **4** PC Access Your Camera

🔳 Foscam VMS 🧧

Foscam VMS is a new tool for PCs. It does not require plug-ins and is compatible with Windows & Mac, supporting all Foscam HD cameras and up to 36 cameras at the same time. If you would like to manage multiple cameras, we suggest you install Foscam VMS. You can download the "Foscam VMS "Windows version from **foscam.com/vms**, and can download the "Foscam VMS" Mac version from the APP store:

https://apps.apple.com/cn/app/foscamvms/id1521202507?mt=12


**Note:** For the best experience, please update Foscam VMS to the latest version!

#### Add the IP Camera


1. Run Foscam VMS, then create a local administrator account and login.

2. Tap the "+" icon on the Foscam VMS and follow the setup wizard to add vour camera.

Please visit foscam.com/downloads to view the user manual and for additional detailed steps.



#### **5** Hardware Installation



Point the camera at the desired location and use the screws provided to mount it.

#### Please Note:

Ensure that rain or water will not reach the connector ports at the end of the pig tail wiring. These connectors are not weather-resistant.


#### **6** Important Notice

#### Camera Username & Password

The camera username & password are used to access and manage your camera. Having a strong password can significantly improve the security of your camera. If you have forgotten either of them, please press the "Reset"




Press the "Reset" button and hold it for more than 3~5 seconds





#### Storage Media


button.


Your camera supports cloud, NVR (Network Video Recorder). and Micro SD card (supports FAT32 and exFAT format) storage formats.












Safety Tips







Keep away from children



Keep dry

Caution Electricity

Not a

children's tov

### 7 Product Performance

WLAN frequency range	2412MHz - 2472MHz and 5725MHz - 5850MHz
Maximum transmission power	< 19dBm
Wireless Standard	IEEE802.11b/g/n (2.4GHz) IEEE802.11a/n/ac (5GHz)
Power Supply	DC 12V 1.0A 12W

# 



from fire



Use the correct power supply



screw pack

- Use the supplied

Then please open the Foscam app to scan the OR-code of your camera to set up the wireless connection for the camera. Please make sure your cellphone is connected to that new WiFi.



## **8** Troubleshooting

#### • IP cameras is not powering on

- If you find your camera is not powering on, please the following:
- 1. Please check whether the outlet is working properly or not. Try to plug the camera into a different outlet and see whether it will work.
- 2. Please check whether the DC adapter is working or not. If you have another 12V/1A power adapter which is working, please try with another power adapter and see whether it will work.
- 3. If it still won't work, please contact Foscam support.

#### • How to re-configure the WiFi connection for Foscam cameras after router changed?

- 1. Please connect the camera to your router with an ethernet cable. If you can see the camera live video on the Foscam app, please go to camera settings-->WiFi settings to choose the new WiFi name and input WiFi password to set up. After the WiFi settings is completed, please disconnect the ethernet cable from the camera and wait for some seconds to connect to the camera.
- 2. There is a need to reset the camera first. Please refer to https://www.foscam.com/fags/view.html?id=13 to see the reset steps

#### support@foscam.com



## C € F© ヒK 🗵

CE Certificate statement Website: https://www.foscam.com/company/ce-certificate.html

Exporter and Importer Information Opened to Public: https://www.foscam.com/company/open-information.html



Manufacturer: Shenzhen Foscam Intelligent Technology Co., Ltd

Addr: Room 901, Unit B, Building 7, Xingke 1st Street Vanke Cloud City Phase 1, Nanshan Dist., Shenzhen, 518055. China

#### www.foscam.com

Due to product upgrades and other reasons, this guide may be slow to update, resulting in slight inconsistencies with the official website information. Please take the official website (www.foscam.com) information as the current standard.