



## HEATIT Z-PUSH BUTTON 4 WHITE

**EOL**

Push button for Z-Wave

**Art.no** 4512682

**GTIN** 7071236015109

Heatit Z-Push Button4 is a battery operated wall switch with 4 push-buttons. The switch enables you to control the Z-Wave-products in your smart home system. Managing your Z-Wave products becomes easy and practical. The switch can be set up to control scenarios or work in associations with other Z-Wave products.

Heatit Z-Push Button4 can control 2 association groups with up to 10 products or up to 8 scenarios through your gateway. Heatit Z-Push Button4 may not be used as a stand-alone unit; it must be included in a gateway to function.

The switch fits into System 55 frames.

The switch is easy to install, and may be fastened with screws or double-sided tape.

### IOT / SMART HOME SPECIFIC DATA

Z-Wave Frequency	Z-Wave - 868.4 MHz (EU)
Z-Wave Chip	Z-Wave 500 chip
Min radio frequency range	40m
Push buttons	4 push buttons
FLiRS	No

### ELECTRO TECHNICAL DATA

Voltage	Batteri 1 x CR2450
---------	--------------------



## MAINTENANCE

The device is maintenance-free.

## STANDARDS

EN Standards	RoHS 2011/65/EU CE	Certification	Z-Wave Plus CE
IP Code	IP20		


## LOGISTICAL DATA (F-PACK)

Width	0mm	Height/diameter	0mm
Length	0mm	Weight	0g
GTIN	-	Unit	
Consists of unit		Quantity	

## DISCLAIMER

All electrical installations must be carried out by an authorized electrical installer.  
The product must be installed in accordance with our installers manual and national building codes. Any wrongful installation, misuse, damage of the product, is not covered under warranty.

Updated documentation is available at [www.thermo-floor.no/www.heatit.com](http://www.thermo-floor.no/www.heatit.com) og/eller [documents.thermo-floor.no/documents.heatit.com](http://documents.thermo-floor.no/documents.heatit.com)  
Thermo-Floor AS/Heatit Controls AB can not be held liable for any type of errors or omissions in our product information.  
Product specifications may change without further notice.



**Heatit Z-Push Button 4 white can be ordered from**  
**[www.thermo-floor.no/4512682](http://www.thermo-floor.no/4512682)**

All additional documentation are available on the above adress and on **[documents.thermo-floor.no/4512682](http://documents.thermo-floor.no/4512682)**

