

HEATIT Z-TEMP3 THERMOSTAT

WHAT CAN YOU USE IT FOR?



HEATIT Z-WATER2
Waterbased heating



HEATIT ZM THERMOSTAT



HEATIT ZM SINGLE RELAY
Ceiling heating



HEATIT ZM SINGLE RELAY
Heating cable



HEATIT Z-TRM6



HEATIT Z-TRM3

WATERBASED HEATING

Control your waterbased heating with Heatit Z-Temp3 Thermostat and Heatit Z-Water2.

CEILING HEATING

For overall heating and local heating use the thermostat with Heatit ZM Single Relay to control your Heatit Radiant Ceiling Heating panel.

HEATING CABLE

Control the connection of heating cables in another room (e.g., in the hallway outside the bathroom). You can also control the connection of heating cables in the fuse box together with Heatit ZM Single Relay.

USE AS A MASTER THERMOSTAT

Control other thermostats in your home, like the Heatit ZM Thermostat, Heatit Z-TRM6 and Heatit Z-TRM3.