## **Wheat**it

### DATA SHEET

Document generated 29. Aug 2025 kl. 17:00







ZeroX<sup>™</sup> detection

Relay status icon

Single poled switch

Lock mode/child lock

• Weekly schedule in app

Active power metering

• Firmware update (OTA)

Open window detection

Adjustable display brightness

#### **PRODUCT FEATURES**

- Wi-Fi (2.4GHz)/BLE thermostat
- Open API for integration
- LCD display
- Internal room sensor
- Floor sensor
- 3 modes: Heat Cool Eco
- Power regulator
- Temperature limiter
- Temperature calibration
- Hysteresis/PWM
- Profiles; Home Away Night Holiday
- External room sensor (wired by cable)
- Google Home and Amazone Alexa (pending)

#### **PRODUCT DATA**

Colour	White RAL 9003
Material	Polycarbonate (PC)
Mounting	European Junction Box
Min. and max ambient humidity (RH%)	10 to 85%
Ambient temperature range in use	5 to 40°C
Ambient temperature range in storage	-30 to 70°C
Min/max installation temperature	5 to 40°C

#### THERMOSTAT DATA

Compatible NTC-sensors (kΩ @ 25°C)	6.8, 10, 12, 15, 22, 33, 47, 100	
Power regulator	Timed cycle 0-30 minutes	
Error margin temperature	0,5	
Temperature sensitivity	±0,5	
Hysteresis	0,3 to 3,0 (default hysteresis 0,5)	
Ohm value at 25°C	10kΩ	
Max length of NTC sensor	50m	
Regulation temperature	5 to 40°C	

#### **ADDITIONAL INFO**

IP Code	IP21
Certification	Reach, RoHS
EN Standards	CE, Nemko
Warranty international	2 years
Customs number	90321000
Country of origin	CN

#### **HEATIT WIFI6 WHITE RAL 9003**

#### Wi-Fi Thermostat 3600W 16A

Art.no	5430542
GTIN	7071236018117

Smart thermostat. Heatit WiFi6 is an electronic thermostat designed for electrical heating and water based heating control. The thermostat can be controlled via Wi-Fi or Bluetooth (BLE) using the "MyHeatit" App or with the buttons on the front of the thermostat. The thermostat features a user-friendly interface, complies with the Eco-Design directive and has an easy-to-read LCD display.

Heatit WiFi6 has 3 modes: Heat - Cool and Eco.

The thermostat fits in standard European junction boxes and may be used with most System 55 frames. It has a sturdy metal frame for secure fastening in the junction box. The thermostat has a built-in room temperature sensor. Two additional external temperature sensors may also be connected.

The installer configures the system via Wi-Fi. If Wi-Fi is not available, the system can be configured via Bluetooth. After the system is set up, the installer can add the property to the customer. The customer can then add the system to their local Wi-Fi network.

All our new Heatit products with Wi-Fi support will be supported through our app; "MyHeatit". In the "MyHeatit" App, you can create your own profiles such as "Home – Away – Night – Holiday" and thus control, monitor and organize all the connected devices, or control them via weekly schedule.

When used with Wi-Fi, the thermostat can communicate over a local API, allowing the user to integrate it with a local gateway, server, controller that offers such a service, without the need to connect it to the cloud. The device also supports Amazon Alexa and Google Home (support for Amazon Alexa and Google Home is pending).

Heatit WiFi6 features active power metering, providing real-time information about your power consumption. It also allows you to manually set the power metering value when connected to a contactor.

The device is equipped with ZeroX $^{\rm M}$  technology, which ensures the relay switches at 0V when turning on and off. This technology significantly extends the thermostat's lifespan.

The thermostat can withstand a resistive load of up to 16A/3600W at 230VAC. For loads above 13A, we recommend using a contactor.

The thermostat is designed for resistive loads. When using large resistive, capacitive, or inductive loads, a contactor should be used.

#### **IOT / SMART HOME SPECIFIC DATA**

Alternate IoT-communication protocols	Bluetooth <sup>®</sup> low energy WiFi (802.11 b/g/n) 2,4GHz
Min radio frequency range	30m
Over The Air update (OTA)	Yes
Push buttons	3
Temperature measurement range	5 to 40°C
Primary IoT Protocol	WiFi Bluetooth

#### **ELECTRO TECHNICAL DATA**

Voltage	230VAC 50Hz
Max load (resistive load)	3600W
Own power usage	2W
Switch type	One-pole switch
Max load (resistive load)	16A
Method of regulation	Button regulation Regulation via App
Connection type	Screw clamps
Connection terminals diameter	0.2 to 2.5mm <sup>2</sup>
Max tightening torque connections	2N·m
Voltage Output	230VAC 50Hz
Grounding	No



Heatit Controls AS Mattisrudsvingen 19, 2827 Hunndalen, Norway Tel: +47 61 18 77 77 | post@heatit.com heatit.com | documents.heatit.com











#### PRODUCT DIMENSIONS

Product height/diameter	84mm	Product Width	84mm
Product length	45.5mm	Product net weight	136g

#### MAINTENANCE

The device is maintenance-free. Indoor use only.

#### ADDITIONAL INFORMATION

Approved for use in bathrooms.

ZeroX<sup>™</sup> Detection is pronounced Zero Cross Detection.

Heatit Controls AB declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

#### **RETURN AND RECYCLING**

The product must be recycled as electronic waste.

#### DISCLAIMER

The thermostat can withstand a resistive load of up to 16A/3600W at 230VAC. For loads above 13A, we recommend using a contactor.

Never change the front from one thermostat to another.

General info;

Worth noting regarding correct installation of thermostats.

When two or more thermostats are mounted too close to each other, the heat they emit, can interfere with the temperature sensors and the temperature in the junction box becomes too high. This can cause inaccurate temperature readings, especially under high load, leading to incorrect heating control. To avoid such issues, thermostats should be installed as far apart as possible and always in separate junction boxes. This ensures more accurate temperature readings.

In multi-frames with multiple units, the thermostat should always be mounted at the bottom, and no more than one thermostat should ever be installed in a multi-frame.

We develop and design our products according in accordance with our strict guality requirements (ISO 9001) and environmental requirements (ISO 14001).

All electrical installations must be carried out by an authorized electrical installer. The product must be installed in accordance with our installers manual and national building codes. Any wrongful installation, misuse, damage of the product, is not covered under warranty.

Updated documentation is available at www.heatit.com and/or documents.heatit.com Heatit Controls AS can not be held liable for any type of errors or omittances in our product information. Product specifications may change without further notice.











## HEATIT WIFI6 THERMOSTAT DIMENSIONS

45.5mm 22mm 23.5mm 50mm 50mm 50mm

# Heatit WiFi6 White RAL 9003 can be ordered from www.heatit.com/5430542

All additional documentation are available on the above adress and on documents.heatit.com/5430542









 $\mathbb{N}$  (  $\mathbb{E}$