



### **PRODUCT FEATURES**

- External sensor
- For indoor use
- Fits into combination frames
- Designed for use with Multireg- and Heatit thermostats
- Can be mounted directly on the wall or on top of a wall box
- · Connected by cable to the thermostat

PRODUCT DATA	
Colour	Black
Min. and max ambient humidity (RH%)	10 to 85%
Ambient temperature range in use	5 to 40°C
Ambient temperature range in storage	-30 to -70°C

STANDARDS	
Certification	RoHS, Reach
EN Standards	CE
IP Code	IP21

WARRANTY	
Warranty international	2 years

# HEATIT EXTERNAL ROOM SENSOR BLACK MATT

External room sensor NTC 10kΩ

**Art.no** 5430133

**GTIN** 7071236016519

Heatit External Room Sensor is designed for use with Multireg and Heatit thermostats. The sensor can be mounted directly on a wall or on top of a standard European wall box. It can be used with most frames that are adapted to System 55. The product comes in a matt version.

When used with a thermostat, dimmer or other products that emit heat, it is recommended that the sensor be mounted below these other products.

It is not possible to connect the sensors in series or in parallel.









PRODUCT DIMENSIONS					
Product height/diameter	30mm	Product Width	90mm		
Product length	90mm	Product net weight	80g		

#### **MAINTENANCE**

The device is maintenance-free. Indoor use only.

## **ADDITIONAL INFORMATION**

Cross-section cable: Ø1.5mm2

#### PRODUCT INFO RETURN AND RECYCLING

The product must be recycled as electronic waste.

### **DISCLAIMER**

We develop and design our products according in accordance with our strict quality requirements (ISO 9001) and environmental requirements (ISO 14001).


All electrical installations must be carried out by an authorized electrical installer. The product must be installed in accordance with our installers manual and national building codes. Any wrongful installation, misuse, damage of the product, is not covered under warranty.

Updated documentation is available at www.heatit.com and/or documents.heatit.com Heatit Controls AB can not be held liable for any type of errors or omittances in our product information. Product specifications may change without further notice.









# Heatit External Room Sensor Black Matt can be ordered from www.heatit.com/5430133

All additional documentation are available on the above adress and on **documents.heatit.com/5430133** 



