‖heatit

HEATIT Z-WAVE THERMOSTAT 16A `EOL`

Black RAL 9011

Art.no	5430498
GTIN	7071236011927

Heatit Z-Wave is an electronic thermostat for electric floor heating. Mounted in a standard wall box. The thermostat has a built-in Z-Wave chip that can be connected to control systems such as Fibaro, Futurehome, Vera, Zipato, Smarthings, Homeseer and more.

Heatit Z-Wave is equipped with a single-pole switch and fits into most frames used in Norway (Elko RS16, Schneider Exxact and Norvesco). The thermostat can withstand a load of max. 16A/3600W at 230V. At higher loads, the thermostat must control a contactor. The thermostat can be connected to two external sensors.

The thermostat can be connected in 8 associations, so that it can, for example, control 8 external relays, wall plugs etc.

The thermostat is designed for electric heating.

PRODUCT FEATURES

- Floor sensor
- Internal room sensor
- External room sensor
- Temperature limiter
- Power regulator
- Z-Wave Plus chip, 500 series
- LED diode
- Lock/Child lock
- Calibration
- 8 associations
- Weekly programme/night timer/day timer via gateway
- Can be used together with various types of NTC sensors

THERMOSTAT DATA

Max length of NTC sensor	50m

ADDITIONAL INFO

Certification	CE

‖heatit CONTROLS

Heatit Controls AS
Mattisrudsvingen 19, 2827 Hunndalen, Norway
Tel: +47 61 18 77 77 | post@heatit.com
heatit.com | **documents.heatit.com**

C€

Ver. EN2506-25
Page:1/3

PRODUCT DIMENSIONS

Product height/diameter	49.5mm	Product Width	49.5mm
Product length	43mm		

MAINTENANCE

The product does not need maintenance, but it must never be covered.

ADDITIONAL INFORMATION

Heatit Controls AB declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

DISCLAIMER

We develop and design our products according in accordance with our strict quality requirements (ISO 9001) and environmental requirements (ISO 14001).
All electrical installations must be carried out by an authorized electrical installer. The product must be installed in accordance with our installers manual and national building codes. Any wrongful installation, misuse, damage of the product, is not covered under warranty.

Updated documentation is available at www.heatit.com and/or documents.heatit.com
Heatit Controls AS can not be held liable for any type of errors or omittances in our product information.
Product specifications may change without further notice.

Heatit Controls AS
Mattisrudsvingen 19, 2827 Hunndalen, Norway
Tel: +47 61 18 77 77 | post@heatit.com
heatit.com | **documents.heatit.com**

C E

Ver. EN2506-25
Page:2/3

Heatit Z-Wave thermostat 16A can be ordered from www.heatit.com/5430498

All additional documentation are available on the above adress and on **documents.heatit.com/5430498**

‖ heatit
CONTROLS

Heatit Controls AS
Mattisrudsvingen 19, 2827 Hunndalen, Norway
Tel: +47 61 18 77 77 | post@heatit.com
heatit.com | **documents.heatit.com**

CE

Ver. EN2506-25
Page:3/3